

# SignatureGem™ LCD 1x5



Model T-L462

## Electronic Signature Pad with Interactive LCD display

SignatureGem LCD 1x5 is a complete and versatile pen-input system for the capture of signatures used in countertop, desktop, or portable applications. The LCD can also be used to display text and graphics from the host computer and pen-tap hot spots allows users to navigate between multiple screens and forms, inputting information or checking preferred options. Bundled software includes development tools for ActiveX, Java, C++, .NET, and Unix/Linux plus plug-ins for MS Word and Excel and Adobe Acrobat.

### Sensor Type

Active Electromagnetic

### Pen Type

Active Energized

### Dimensions

6" x 3.8" x 0.70"  
152 x 97 x 18mm

### Signing Area

4.4" x 1.3"  
112 x 33mm

### Data conversion rate

377 points per second

### Resolution

410 true points per inch

### Support

Updates are provided free of charge

### Authentication capability

Forensic-quality .SIG data capable of examination and authentication with Topaz SigAnalyze™ software (US Patent 6,307,955)

### Warranty

3 years, with renewal option

## Bundled Software

### Developer's Tools

ActiveX

Java and J2ME

C++

.NET

Tablet PC

Unix/Linux

### Plug-Ins

MS Word, Excel

Adobe Acrobat

### Applications and Utilities

SigPlus Adjust

SigTool Imager

SignMeln

### Verification

SigValid

SigCompare

SigAnalyze

650 Cochran Street Suite 6 Simi Valley, CA 93065  
phone 805 520 8282 fax 805 520 0867

specifications subject to change without notice

